Manic SPS Switch

Performance Level Setting Instructions

When making performance level changes the engine can be running. For safety please STOP the car before making any ECU performance level changes.

Do not attempt to make ECU performance level changes while the car is moving.

1. Select switch position on the SPS for the desired Performance Level
2. Plug SPS into OBDII Port under the dash, adjacent to the left side foot well panel (kick panel)
3. When you hear "3 CONSECUTIVE BEEP... performance level change has been completed. The 3 BEEP SEQUENCE will con... PS switch is removed.
4. Remove the SPS from ...

CAUTION: Do n... e else to re-flash your ECU with a stock or any other pro... Manic Performance Tune. It cannot be restored for free... e paid again to get the performance flash re-installed. ...ting software lock installed by Manic)

SPS Settings

SWITCH POSITION 0 = DO NOT USE

SWITCH POSITION 1 = Stock Power Level

SWITCH POSITION 2 = Performance Level A (approx. 25% of total power increase)

SWITCH POSITION 3 = Performance Level B (approx. 50% of total power increase)

SWITCH POSITION 4 = Performance Level C | MAXIMUM POWER | (100% power increase)

SWITCH POSITION 5-9 = NOT USED

REV August 16, 2017