


VIN: XXXXXXXX Vehicle: MINI/F56/HAT/Cooper/B38/AUTO/USA/LL/2014/11

System Version: 3.47.10.13054 Data Version: R3.47.10.13054

61 31 ... Removing and installing (replacing) the driving experience switch



Removal:




Unclip bezel with driving experience switch (2) by lifting it up.




Unlock and disconnect connector on driving experience switch (1).

Detach retaining ring with gaiter (1) from bezel with driving experience switch (2).




Installation:



Note:

The clamps on the holder (3) must not be damaged or missing.
Latch mechanisms (1) on the bezel (2) must not be damaged or missing.




Insert retaining ring with gaiter (3) into bezel with driving experience switch (2).

Note:

The guide lug (1) must snap into place in the guide.

Connect connector (1) to driving experience switch.



Clip in bezel with driving experience switch (2) by pushing it down.