

1. Drive the vehicle in 4th gear at 40-50 mph (60-80 kmh)
2. Depress the clutch pedal
3. Rev the engine up to 5,500-6,000 rpm and maintain this engine speed.
4. Slowly release the clutch pedal, keeping the engine speed at 5,500-6,000 rpm in the process until the clutch is fully engaged. (Clutch engagement must be carried out within 3 seconds)
5. Repeat steps 1-4 at least 3 times.
6. Recheck vehicle to verify that the noise has subsided.

Let me know if this helps.

**New Additional information**

---

© 2002-2007 BMW OF NORTH AMERICA, LLC. ALL RIGHTS RESERVED.